



AP-309673 (Installation Instructions for 05-15 Tacoma Double Cab Roof Molle Rack, Kit AP-309675)







WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov



AP-309673





1. Pop off the plastic covers on each side of the factory grab handles. Remove the (2) mounting screws that hold the factory grab handles to the roof. Repeat this process on the other side of the vehicle.





2. Mount any molle accessories you plan on using to the rack. If possible, mount heavier accessories towards the sides of the rack close to the rack mounting tabs.



3. Position the rack on the interior of the roof and align the mounting slots in the rack with the mounting holes in the roof. Use the original grab handle mounting bolts to bolt the rack to the roof. If desired, place the original grab handles or after-market grab handles over the mounting holes in the rack and reinstall the mounting bolts.

